

Area Imaging Bar Code Supplemental Configuration

Serial Port Emulation (not necessary)



1. Recall Defaults



2. Enter Configuration Mode



3. Configurable Suffix Character #1



4. Code Byte 0



5. Code Byte 3

6. Code Byte 6



7. Configurable Suffix Character #2



8. Code Byte 1



9. Code Byte 0



10. Code Byte 3



11. Exit Configuration Mode

